
























CR Series



Edit:15.01




S01  x2	S03  x4	S04  x8	S05  ST4 x18	S06  x4	S07  x4
S08  x2	S09  ST4 x4	S10  x8	S11  x4	S12  x4	S13  ST4 x16
S15  x2	S16  x2	S17  x14			




1




2




3




4



5




6




S09

S05


7




8




9



10




11






TOP ROLLER



BOTTOM ROLLER



12



13



Adjust the top rollers in the event of glass door is not leveled

14

